

Pegasus

Ultracoustic

Installation Guide

Congratulations!

Congratulations on purchasing the Pegasus Acoustic Panels from Ultracoustic. The Ultracoustic Pegasus Panels is a package of easy to install acoustic panels, that will effectively diffuser a broad bandwidth of frequencies and look great for years to come. The Pegasus panels are ideally suited to provide effective acoustic control in applications as diverse as home-theatres, practice rooms, house of worship, offices, call centers & broadcast studios.

Please take a few minutes to read through this install manual.

It includes a list of parts as well as step by step mounting instructions.

Please refer to www.ultracousticin.com for various placement options, benefits and general room acoustic information.

Should you have any questions or comments,
we invite you to send us an email at : info@ultracousticin.com

Installation Instructions:

Wall surfaces should be examined prior to installation, ensuring they are clean, smooth, and dry.

INSTALLING SURFACE CLIPS AND WALL PANELS

ULTRACOUSTIC surface clips are designed to provide the installer with a simple and effective method of mounting Pegasus panels onto walls. The mounting clips feature a male - female arrangement.


STEP 1 : Use a bubble level to make a straight pencil line where the top of the panel will be, Measure along this line carefully mark where the corner of each panel will be. if you are planning to space panels apart include the gap measurement between panels.

STEP 2 : hold the surface clips up to the wall opposite direction as to that of clips on the panel and mark the holes for screwing. precise mounting is necessary.

STEP 3 : Just hold the panel and the clips of the panel into the clips screwed on the wall.


Installation Steps:

1 .




Measure the distance between the clips behind the panel

2 .




Mark the clips on the wall at the same distance as that of the clips behind the panel. Screw the clips on the wall after checking it with level meter

3 .



The clips are in the arrangement of male-female. just pick up the panel and push it into the clips screwed on the wall.

4 .



The panel will hang on the clips securely.

Warranty:

Please inspect panels immediately after purchase and before mounting.

Ultracoustic acoustic panels are guaranteed to be free of manufacturing defects for a period of fifteen (15) days after purchase.

In the unlikely event that a defect is uncovered, please call 91-72089 07208 to obtain RA number from Ultracoustic before the fifteen (15) day warranty period expires.

Once you have obtained an RA number you must return the product, freight prepaid with ten (10) days after the date the RA number is issued.

Please return the product in the original packaging

(or another, affording an equal degree protection) with all of the following:

- (1) RA number clearly marked on the returned package;
- (2) A receipt or bill of sale showing proof of purchase from an authorized retail seller; and
- (3) A written note describing the defect and including your name, address, telephone number and the applicable RA number.

You are solely responsible for all shipping and insurance costs returning the product to Ultracoustic and you will not be reimbursed or compensated for any loss or damage incurred during return shipping. Ultracoustic will at its discretion repair or replace the panel.

Should the panel be no longer available, Ultracoustic reserves the right to exchange this with a panel of similar performance and value. Due to different dye lots, Ultracoustic cannot guarantee exact colour match. This Warranty shall solely extend to the original owner and is limited to manufacturing defects only and excludes damage due to improper installation, freight handling, wear and tear, abuse, misuse, Misapplication, colour fading or deterioration due to prolonged exposure to ultra violet light, smoke, humidity or other environmental factors. It is understood that the use and suitability of our acoustic panels is entirely the responsibility of the buyer or specifying engineer and as such, these parties agree to hold Ultracoustic, or its associated company, and/or offers, harmless from any responsibility whatsoever other than what is clearly outlined in the warranty.

Contact Us:

Address:

Ultracoustic is a division of A R Acoustics LLP. 504, Jupiter, Gaurav Galaxy, Phase II, Mumbai - 401107.

Telephone No:

(9122) 6560-6002 | 2945 1202

Mobile No.: 72089 07208

Email: info@ultracousticin.com

Follow us on: <https://www.instagram.com/ultracoustic/?hl=en>

Specifications and appearances subject to change without notice.

Ultracoustic Pegasus manual rev.007 / Part #: R360-xxx-xx Copyright © 2015 All rights reserved.

www.ultracousticin.com